

## Important

### Please read this fully before fitting the kit

Thank you for purchasing a Britpart re-trim kit.

Before you begin fitting this kit please watch the short instructional presentation on the CD included. This 20 minute tutorial will give you a detailed step-by-step guide to disassembling and assembling your Defender seat and information on the correct use of the included parts.

A complete Britpart re-trim kit should include:

- 1 x Fitment Guide CD
- 1 x Can of Contact Adhesive Spray
- 1 x Cushion Foam
- 1 x Squab Foam
- 1 x Cushion Cover
- 1 x Squab Cover
- 1 x Headrest Cover
- 6 x Plastic Nails
- 2 x Metal Rods
- 3 x Cable Ties
- 1 x Rubber Retainer

If any of the above parts are found to be missing from your kit please contact your supplier.

#### PLAYING THE FITMENT GUIDE CD-ROM

A PC with a CD-ROM & Windows Media Player (included on the CD) will be required to watch the Fitment Guide.

To view the guide on the CD simply put the disc into your CD-ROM, wait for the menu to load and then follow the on screen instructions. If your CD-ROM does not automatically run please select your CD drive in 'My Computer' and load the index.htm file present on the disc.

**WARNING:** All aspects of health and safety should be observed while fitting this part and Britpart will not be held responsible for any injury caused during the installation or use of this kit. The included Contact Adhesive Spray must only be used in a well ventilated area and the instructions on the can should be read fully before commencing.